


INSTRUCTIONS

The lock is pre-set to 0-0-0.



TO LOCK: Adjust the luggage strap so that it fits tightly around the luggage and hook the strap-head over the locking tab (A). With the dials (B) set to the correct combination, close the lock cover and then scramble the dials to lock.

TO UNLOCK: Set the correct combination using the dials, then press the cover release button (C) and open the lock cover. Remove the strap head from the locking tab to unlock.

TO SET THE COMBINATION CODE: Unlock as described above. With the dials set the the current combination, pull the code-change lever (D) upwards until it is in an upright position. Turn the dials to the new combination and then push the code-change lever back to its normal position. The new combination is now set.

TO RESET THE TSA ENTRY INDICATOR: The TSA entry indicator (E) is located on the lock cover. If customs screeners have accessed the luggage, the indicator will show red. To turn the indicator back to green, unlock as described above and then push the green tab (F) from the left side to the right side.